




blak CD Player



blak CD Player

Warning: Laser Safety

This unit employs a laser. Only qualified persons should remove the cover or attempt to service this unit due to the risk of eye injury.



Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



This manual is divided into the following sections:

- Safety Instructions (accompanying card)
- Introduction
- Cautions
- Installation
- Setup
- Operation
- Troubleshooting
- Guarantee
- Specifications

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



INTRODUCTION

Congratulations on your purchase of the Roksan **blak** CD Player. This CD Player is designed and manufactured to the highest specification and rigorously tested to reward you with many years of listening pleasure.

Your **blak** CD Player is an integral part of your system. Its correct installation, set-up and operation will have a significant influence on the performance of the entire hi-fi installation.

Please read the contents of this manual thoroughly. It will help you to understand your hi-fi equipment better and further enhance your listening pleasure.

UNPACKING

Included in the packing of your **blak** CD Player you will find:

- One mains lead fitted with the correct mains power plug for your country
- One Roksan R7 V.3 remote control

After disconnecting the **blak** CD Player from the mains supply, the cabinet and front panel may be cleaned with a lightly dampened soft cloth or chamois leather. Avoid using abrasives or sol-

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



CAUTIONS

AC MAINS SUPPLY

Your **blak** CD Player is set to operate from a fixed supply voltage which is marked on a label next to the mains input plug. Before connecting the mains lead please check that your mains supply corresponds to this label as below:

230V Products: Voltage Range: 220V - 240V

115V Products: Voltage Range: 110V - 120V

100V Products: Voltage Range: 90V - 110V

The mains lead supplied with this product has an IEC mains socket which plugs into the IEC connector on the unit's rear panel. The other end is normally attached to the appropriate mains plug for your country. In the UK this is the standard BS1363 plug.

If the plug becomes damaged or is not suitable for your socket outlet, it should be cut off and an appropriate plug fitted in its place by a qualified service personnel.

The replacement plug should have the same fuse rating as the original plug. The severed plug must be disposed of to avoid a possible shock hazard and should never be inserted into a mains socket elsewhere.

This plug should usually not be removed from the lead. If you do remove it, please dispose of it safely so that it cannot be plugged into a mains socket whilst in a potentially dangerous condition. We suggest that you obtain a complete replacement lead from your dealer.

Should you move to another country where either the mains voltage or the mains plugs are different from those as supplied with your CD Player, please contact the appointed Roksan distributor for assistance.

Please observe correct mains polarity at all times.

The CD Player mains fuses are located on the rear panel next to the IEC mains connector. They must only be replaced by the fuse of the type and rating as described on the fuse rating label on the rear panel of the unit.

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



GENERAL CAUTIONS

LOCATION

Your **blak** CD Player should be located in a well ventilated area and kept away from sources of heat, dust and humidity and out of direct sunlight. The CD Player may be positioned either as a free standing unit or alongside another audio/video product. Never place the player on carpet or any surface likely to hinder normal ventilation.

Never allow liquids or other objects to fall into the unit. This unit contains no user serviceable parts. DO NOT remove any panels or attempt to service it yourself. Unauthorised servicing will void the warranty.

Roksan Audio

CLASSIFICATION: General Use

All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom


website: www.roksan.co.uk email: info@roksan.co.uk

Tel: +44 (0)1268 740580



INSTALLATION

blak CD PLAYER - FRONT PANEL VIEW



- 1. Mains on / off switch
- 2. Display time button
- 3. CD disc tray
- 4. LED display
- 5. Function LEDs
- 6. Track back button
- 7. Track forward button
- 8. Play / Pause button
- 9. Open / Close disc tray button
- 10. Stop button

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



blak CD PLAYER - REAR PANEL VIEW



- 11. Analogue Output - Left & Right. Phono: RCA, Balanced: XLR
- 12. Digital Outputs - Optical: Toslink, Balanced: AES/EBU, Coaxial: RCA
- 13. Voltage & Fuse Label
- 14. AC Mains Fuse Holder
- 15. IEC Mains Inlet Socket

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE



SETUP

CONNECTING MAINS POWER

Please refer to the front & rear panel views.

The moulded IEC connector of the supplied mains lead should be plugged into the socket (15) on the rear of the unit first and then plugged into the mains supply. The mains power switch (10) is on the front underside of the CD Player. This switch can be left on; if however the CD player is likely to be unattended for a long period, switch it off and unplug the mains lead from the wall.

SIGNAL CONNECTIONS

ANALOGUE OUTPUT:

The Analogue Outputs (11) use Gold plated RCA Phono sockets and should be connected to the CD or LINE input of your Preamplifier or Amplifier. Standard convention: Right Channel - Red; Left Channel - Black or White.

DIGITAL OUTPUT:

The Digital Outputs (11) utilise; Gold plated RCA Phono socket for Coaxial SPDIF output, Toslink for Optical output and XLR for Balanced AES/EBU output. Any of these could be connected to a corresponding input of an amplifier with a digital input, or to an outboard Digital to Analogue converter (DAC).

IMPORTANT NOTE:

For optimum performance it is recommended to use high quality inter-connect cables such as Roksan HDC-03A High Definition Analogue Cable and HDC-01D High Definition Coaxial Digital Cable.

Roksan Audio

CLASSIFICATION: General Use

All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



OPERATION

SWITCHING ON

The mains power switch (10) is located on the front underside of the CD Player. This switch can be left ON for normal operation. If unattended for a long period (going on a short break, holidays etc.) the mains power should be switched OFF and the power cord disconnected from the

USING THE CONTROLS

Press the Open/Close Button (9) once to open the disc loading tray. Carefully load disc into the tray recess with the label side up. Press the button again to close the tray.

NOTE: Never load a disc until the drawer has opened fully, or try to close the drawer until you are sure that the disc is properly seated in the holder recess. Warped discs should never be played.

The drawer should only be opened using the front panel control. Under no circumstances should you attempt to open manually.

If a disc is not inserted or if the disc is damaged or inserted upside down, the CD Player will remain inoperative (display will indicate: no disc).

When a disc has been loaded, your **blak** CD Player will briefly spin the disc while it studies the data encoded on it. The disc will then stop and the display will indicate the number of tracks on the disc and the total play time.

To commence playing a disc, press Play/Pause Button (7) once. The disc will play from the beginning.

Press the Play/Pause Button (3) a second time to pause the disc whilst it is playing. Pressing the button again will resume playback from the point at which Pause mode was entered. In Pause mode, the disc continues spinning and the laser will still be operational but locked. Please try not to keep the CD Player in Pause mode no longer than strictly necessary.

Roksan Audio

CLASSIFICATION: General Use

All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



SELECTING A TRACK

Press the Track Forward Button (6) to go to the next track on the disc. Pressing the Track Back Button (5) will take you to the previous track.

When the disc is playing, press the Track Back Button once to take you to the beginning of the current track and a second time to take you to the start of the previous track.

In Play mode press the Track Forward Button (6) to take you forward to the start of the next track. Once the procedure is complete the disc will commence playing from the selected track.

When a disc is first loaded, you can use these buttons to select your desired track. Having done so, press the Play/Pause Button (7) and your disc will commence playing from the selected track.

You may select a track when Pause is engaged. In this case, the disc will revert to Pause after the procedure is complete and you will have to press Play/Pause Button (7) to continue playing the disc.

DISPLAY

Pressing the Time Button (1) on the front panel repeatedly will cycle the display through the following modes:

- Normal: Indicates track number and how long it has been playing.
- First Press: Indicates track number and remaining time on the track.
- Second Press: Indicates number of tracks and remaining time on the disc.

ADJUSTING DISPLAY BRIGHTNESS

Once the CD is in stop Mode, press and hold the Stop Button on the front panel until 'ROKSAN' appears in the display. Use the Next and Previous Track buttons to adjust the brightness of the display.

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



REPEAT FUNCTION


There is a repeat function available on the blak CD Player. Press and hold the time button (1) on the front panel for around three seconds. This will set the 'repeat all' function and the whole disc will replay and the corresponding 'Repeat All' LED light will illuminate in the display panel. To repeat just the current track that is playing, press and hold the time button again. The corresponding 'Repeat' LED light will illuminate. To take the player out of repeat mode, press and hold the time button once more.

NOTE: This function can only be executed via the front panel controls.

REMOTE CONTROL FUNCTIONS

The blak CD Player uses the Roksan R7 remote control. The bottom section of the remote is dedicated to the CD Player. Below is an outline of the functions available.

- CD (□): Stop
- CD (▶||): Play/Pause
- Track (◀): Skip to previous track
- Track (▶): Skip to next track
- Shuffle: When in Stop mode, press SHUFFLE to play the tracks in a random order. To cancel press (□)



Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO



TROUBLESHOOTING

If you suspect your **blak** CD Player is not operating properly, first check all the connections carefully. Pay particular attention to input and output connections. Phono plugs should be fully inserted - a frequent cause of problems is that Phono plug surrounds do not make proper contact. On this page are some commonly encountered problems with suggestions for possible cure. The list is not exhaustive, if you have any unresolved problems, please consult Roksan or your appointed Roksan dealer or distributor.

SYMPTOM	LIKELY CAUSE	SUGGESTED REMEDY
The disc tray will not close when a disc is inserted	<ul style="list-style-type: none"> • Disc not placed properly in tray • Disc is warped 	<ul style="list-style-type: none"> • Re-place disc properly • Discard disc
Disc inserts, display does not show the number of tracks and playing time	<ul style="list-style-type: none"> • Disc inserted upside down • Disc is dirty or scratched • Condensation on the laser lens • Dirt on the laser lens 	<ul style="list-style-type: none"> • Re-insert disc label side up • Clean disc, discard scratched disc • Let CD Player warm up and dry out lens <p>*Refer to appointed dealer or service centre DO NOT use CD lens cleaners*</p>
Skipping & mistracking	<ul style="list-style-type: none"> • Excessive vibration • Disc is dirty or scratched 	<ul style="list-style-type: none"> • Ensure player is stable and vibration-free • Clean disc, discard scratched disc
Excessive hum	<ul style="list-style-type: none"> • Connection loose, cable faulty 	<ul style="list-style-type: none"> • Re-connect plugs, change interconnect
One channel inoperative	<ul style="list-style-type: none"> • Interconnect or amplifier faulty 	<ul style="list-style-type: none"> • Change lead, try another line input on amp
Remote handset operation erratic or not working	<ul style="list-style-type: none"> • Batteries weak or wrongly inserted • Handset signal path is obstructed • Handset transmission angle too wide • Room lighting/sunlight excessive 	<ul style="list-style-type: none"> • Replace batteries, observe polarity • Remove obstruction, move handset • Operate handset in front of CD Player • Darken room

Roksan Audio

CLASSIFICATION: General Use

All specifications are liable to change without notice. E&OE

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom

website: www.roksan.co.uk email: info@roksan.co.uk

Tel: +44 (0)1268 740580



GUARANTEE

There are no user-serviceable parts inside your **blak** CD Player. If a fault should develop, refer any servicing to your appointed Roksan dealer, distributor or Roksan approved service agent.

Your **blak** CD Player is guaranteed against any defect in materials and workmanship for a period of five years from the date of purchase.

This guarantee is only effective if the warranty card is validated by the Roksan retailer from whom the equipment was purchased and returned to Roksan within 28 days of purchase.

This guarantee excludes:

- Damage caused due to accident, misuse, neglect and incorrect installation, adjustment or repair.
- Liability for damage or loss during transit from the retailer or purchaser to Roksan or its authorised distributor for the purposes of repair or inspection.

Carriage costs to Roksan shall be borne by the consignor.

All claims under this guarantee must be made through an authorised Roksan retailer. If equipment returned for repair to Roksan is found on inspection to comply with the product specification Roksan reserves the right to make a charge for examination and return carriage.

Unauthorised servicing will void this guarantee.

Roksan Audio declares that the apparatus blak CD Player complies with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

ROKSAN AUDIO



SPECIFICATIONS

Inputs _____ 3 x digital outputs (optical, coaxial, XLR)
_____ 2 x pairs of analogue outputs (RCA, XLR)

Peak output _____ 2.5V

THD _____ @ 1kHz, 0dB less than 0.001%

Linearity _____ @ 1kHz > 89dB

Jitter _____ < 135ps

Maximum power consumption _____ 20W

S/N ratio A weighted _____ > 108dB

Stop band rejection _____ > 100dB

Dimensions (H x W x D) _____ 140 x 440 (inc. faceplate) x 309mm

Weight _____ 8kg

Roksan Audio
CLASSIFICATION: General Use
All specifications are liable to change without notice. E&OE

V1.1, March 2017

ROKSAN AUDIO

Monitor Audio Ltd, 24 Brook Road, Rayleigh, Essex, SS6 7XJ, United Kingdom
website: www.roksan.co.uk email: info@roksan.co.uk
Tel: +44 (0)1268 740580



Roksan Audio

Monitor Audio Limited
24 Brook Road
Rayleigh
Essex
SS6 7XJ

+44 (0)1268 740580
info@roksan.co.uk